

ZHDZ-KCD1/KCD3/KCD4/KCD6/KCD9/KCD11



KCD1-A



KCD1-B



KCD1-C



KCD1-CA



KCD1-D



KCD1-E



KCD1-F



KCD1-G



KCD1-H



KCD1-I



KCD1-J



KCD1-K



KCD1-M




KCD1-N



KCD3-A



■ 底座类型 / BASE



■ 端子类型 / TERMINAL



■ 功能 / FUNCTION

101	ON-OFF	
102	ON-ON	



KCD3-AA



KCD3-B



KCD3-C



KCD3-D



KCD3-DA



KCD3-E



KCD4-A



KCD4-B



KCD4-BA



KCD6-A



KCD6-B



KCD9-A



KCD9-B




























KCD11-A



KCD11-B

跳板开关移印方案选择

SPRINGBOARD SWITCH PRINTING SCHEME SELECTION

- | | | | | | | | |
|---|---|---|---|---|--|---|---|
| A |  | B |  | C |  | D |  |
| E |  | F |  | G |  | H |  |
| I |  | J |  | K |  | L |  |
| M |  | N |  | O |  | P |  |
| Q |  | R |  | S |  | T |  |
| U |  | V |  | W |  | X |  |
| Y |  | | | | | | |